

16 Channel:

Channel	DMX Value	Function
1	000-255	Pan 0°~ 540°
2	000-255	Tilt 0°~ 210°
3	000-255	Pan&Tilt Speed with decreasing speed
4	000-255	Master Dimmer0%~ 100%
5	000-008	No function
	009-255	LED Strobe with increasing speed
6	000-255	RED LED Dimmer0%~ 100%
7	000-255	Green LED Dimmer0%~ 100%
8	000-255	Blue LED Dimmer0%~ 100%
9	000-255	White LED Dimmer0%~ 100%
10	000-255	5050 SMD Dimmer0%~ 100%
11	000-008	No function
	009-255	5050 SMD Strobe with increasing speed
12 SMD Section 1	000-010	No Function
	011-044	Red
	045-079	Green
	080-114	Blue
	115-149	Red and Green
	150-184	Red and Blue
	185-219	Green and Blue
	220-255	5050 SMD section 1 RGB
13 SMD Section2	000-010	No Function
	011-044	Red
	045-079	Green
	080-114	Blue
	115-149	Red and Green
	150-184	Red and Blue
	185-219	Green andBlue
	220-255	RGB
14 SMD Section 3	000-010	No Function
	011-044	Red
	045-079	Green
	080-114	Blue
	115-149	Red and Green
	150-184	Red and Blue
	185-219	Green and Blue
	220-255	RGB
15 SMD Section 4	000-010	No Function
	011-044	Red
	045-079	Green
	080-114	Blue
	115-149	Red and Green
	150-184	Red and Blue
	185-219	Green and Blue
	220-255	RGB
16	000-199	No function
	200-209	Reset
	210-239	No function
	240-255	Sound Active

21 Channel:

Channel	DMX Value	Function
1	000-255	Pan 0°~ 540°
2	000-255	Pan Fine
3	000-255	Tilt 0°~ 210°
4	000-255	Tilt Fine
5	000-255	Pan&Tilt Speed with increasing speed
6	000-255	LED Dimmer0%~ 100%
7	000-008	No function
	009-255	LED Strobe with increasing speed
8	000-255	RED LED Dimmer0%~ 100%
9	000-255	Green LED Dimmer0%~ 100%
10	000-255	Blue LED Dimmer0%~ 100%
11	000-255	White LED Dimmer0%~ 100%
12	000-255	5050 SMD Dimmer0%~ 100%
13	000-008	No function
	009-255	5050 SMD Strobe slow to fast
14	000-255	5050 SMD RED Dimmer0%~ 100%
15	000-255	5050 SMD Green Dimmer0%~ 100%
16	000-255	5050 SMD Blue Dimmer0%~ 100%
17 SMD Section1	000-010	No Function
	011-044	Red
	045-079	Green
	080-114	Blue
	115-149	Red and Green
	150-184	Red and Blue
	185-219	Green and Blue
	220-255	RGB
18 SMD Section2	000-010	No Function
	011-044	5050 SMD section 2 Red
	045-079	5050 SMD section 2 Green
	080-114	5050 SMD section 2 Blue
	115-149	5050 SMD section 2 Red mix Green
	150-184	5050 SMD section 2 Red mix Blue
	185-219	5050 SMD section 2 Green mix Blue
	220-255	5050 SMD section 2 RGB
19 SMD Section3	000-010	No Function
	011-044	Red
	045-079	Green
	080-114	Blue
	115-149	Red and Green
	150-184	Red and Blue
	185-219	Green and Blue
	220-255	RGB
20 SMD Section4	000-010	No Function
	011-044	Red
	045-079	Green
	080-114	Blue
	115-149	Red and Green
	150-184	Red and Blue
	185-219	Green and Blue
	220-255	RGB
21	000-199	No function
	200-209	Reset
	210-239	No function
	240-255	Sound Active