

Mode/Channel		Value	Function
CH24	CH12		
1	1		Dimmer
		0..255	Dimmer 0%...100%
2	2		Shutter
		0..31	Shutter closed
		32..63	shutter open
		64..95	Strobe effect slow to fast
		96..127	shutter open
		128..159	Pulse-effect in sequences slow to fast
		160..191	shutter open
		192..223	Random strobe effect slow to fast
224..255	shutter open		
3	3		Red
		0..255	0-100% Red dimmer from dark to bright
4	4		Green
		0..255	0-100% Green dimmer from dark to bright
5	5		Blue
		0..255	0-100% Blue dimmer from dark to bright
6	6		White
		0..255	0-100% White dimmer from dark to bright
7	7		Yellow
		0..255	0-100% Yellow dimmer from dark to bright
8	8		Purple
		0..255	0-100% Purple dimmer from dark to bright
9			Red1
		0..255	0-100% Red1 dimmer from dark to bright
10			Green1
		0..255	0-100% Green1 dimmer from dark to bright
11			Blue1
		0..255	0-100% Blue1 dimmer from dark to bright
12			White1
		0..255	0-100% White1 dimmer from dark to bright
13			Yellow1
		0..255	0-100% Yellow1 dimmer from dark to bright
14			Purple1
		0..255	0-100% Purple1 dimmer from dark to bright
15		Red2	
	0..255	0-100% Red2 dimmer from dark to bright	
16		Green2	
	0..255	0-100% Green2 dimmer from dark to bright	
17		Blue2	
	0..255	0-100% Blue2 dimmer from dark to bright	
18		White2	
	0..255	0-100% White2 dimmer from dark to bright	
19		Yellow2	
	0..255	0-100% Yellow2 dimmer from dark to bright	
20		Purple2	
	0..255	0-100% Purple2 dimmer from dark to bright	

21	9		Macro Color
		0..15	No Function
		16..31	Red
		32..47	Green
		48..63	Blue
		64..79	White
		80..95	Red+Green
		96..111	Red+Blue
		112..127	Red+White
		128..143	Green+Blue
		144..159	Green+White
		160..175	Blue+White
		176..191	R +G+B
		192..207	R+G+B+W
		208..212	2700K
		213..217	3200K
		218..222	3500K
		223..227	5000K
		228..232	5500K
		233..237	6000K
238..242	6500K		
243..247	7000K		
248..255	8000K		
22	10		Color Temp
		0..15	No Function
		16..45	Below 3200K
		46..75	3200K - 3500K
		76..105	3500K - 5000K
		106..135	5000K - 5500K
		136..165	5500K - 6000K
		166..195	6000K - 6500K
		196..225	6500K - 7000K
		226..255	7000K - 8000K
23	11		Macro RUN
		0..15	No function
		16..31	Macro Run 1
		32..47	Macro Run 2
		48..63	Macro Run 3
		64..79	Macro Run 4
		80..95	Macro Run 5
		96..111	Macro Run 6
		112..127	Macro Run 7
		128..143	Macro Run 8
		144..159	Macro Sound 1
		160..175	Macro Sound 2
		176..191	Macro Sound 3
		192..207	Macro Sound 4
		208..223	Macro Sound 5
224..239	Macro Sound 6		
240..255	Macro Sound 7		
24	12		Macro Speed
		0..255	Macro Speed from Slow To Fast