

| DUO324 channel list |              |              |          |   |
|---------------------|--------------|--------------|----------|---|
| Mode/Channel        |              |              | Value    | Function  |
| Simple<br>14CH      | Same<br>07CH | Full<br>32CH |          | The selection and collocation of different mode.Simple occuppies less channels,Same mode occuppies very few channels,Full is full channel operation |
| 1                   | 1            | 1            |          | <b>Head 1 Dimmer</b>  |
|                     |              |              | 0..255   | Dimmer 0%...100%  |
| 2                   | 2            | 2            |          | <b>Head 1 Shutter</b>   |
|                     |              |              | 0..31    | Shutter Closed  |
|                     |              |              | 32..63   | Shutter Open  |
|                     |              |              | 64..95   | Strobe Effect Slow to Fast  |
|                     |              |              | 96..127  | Shutter Open  |
|                     |              |              | 128..159 | Pulse-effect in Sequences Slow to Fast  |
|                     |              |              | 160..191 | Shutter Open  |
|                     |              |              | 192..223 | Random Strobe Effect Slow to Fast   |
|                     |              |              | 224..255 | Shutter Open  |
| 3                   | 3            | 3            |          | <b>Head 1 Warm White</b>  |
|                     |              |              | 0..255   | 0-100% Warm White Dimmer from Dark to Bright  |
| 4                   | 4            | 4            |          | <b>Head 1 Cold White</b>  |
|                     |              |              | 0..255   | 0-100% Cold White Dimmer from Dark to Bright  |
| 5                   | 5            | 5            |          | <b>Head 1 Color Temp</b>  |
|                     |              |              | 0..15    | No Function   |
|                     |              |              | 16..45   | Below 3200K   |
|                     |              |              | 46..75   | 3200K - 3500K   |
|                     |              |              | 76..105  | 3500K - 5000K   |
|                     |              |              | 106..135 | 5000K - 5500K   |
|                     |              |              | 136..165 | 5500K - 6000K   |
|                     |              |              | 166..195 | 6000K - 6500K   |
|                     |              |              | 196..225 | 6500K - 7000K   |
|                     |              |              | 226..255 | 7000K - 8000K   |
| 6                   | 6            | 6            |          | <b>Head 1 Macro Run</b>   |
|                     |              |              | 0..15    | No function   |
|                     |              |              | 16..27   | Macro Run 1   |
|                     |              |              | 28..39   | Macro Run 2   |
|                     |              |              | 40..51   | Macro Run 3   |
|                     |              |              | 52..63   | Macro Run 4   |
|                     |              |              | 64..75   | Macro Run 5   |
|                     |              |              | 76..87   | Macro Run 6   |
|                     |              |              | 88..99   | Macro Run 7   |
|                     |              |              | 100..111 | Macro Run 8   |
|                     |              |              | 112..123 | Macro Run 9   |

|    |   |    |          |  |
|----|---|----|----------|--|
|    |   |    | 124..135 | Macro Run 10   |
|    |   |    | 136..147 | Macro Run 11   |
|    |   |    | 148..159 | Macro Run 12   |
|    |   |    | 160..171 | Macro Run 13   |
|    |   |    | 172..183 | Macro Run 14   |
|    |   |    | 184..195 | Macro Run 15   |
|    |   |    | 196..207 | Macro Sound 1  |
|    |   |    | 208..219 | Macro Sound 2  |
|    |   |    | 220..231 | Macro Sound 3  |
|    |   |    | 232..243 | Macro Sound 4  |
|    |   |    | 244..255 | Macro Sound 5  |
| 7  | 7 | 7  |          | <b>Head 1 Macro Speed</b>                              |
|    |   |    | 0..255   | Macro Speed from Slow To Fast                          |
|    |   | 8  |          | <b>Head 1 Warm White of Ring 1</b>                     |
|    |   |    | 0..255   | 0-100% Warm White of Ring 1 Dimmer from Dark to Bright |
|    |   | 9  |          | <b>Head 1 Cold White of Ring 2</b>                     |
|    |   |    | 0..255   | 0-100% Cold White of Ring 2 Dimmer from Dark to Bright |
|    |   | 10 |          | <b>Head 1 Warm White of Ring 3</b>                     |
|    |   |    | 0..255   | 0-100% Warm White of Ring 3 Dimmer from Dark to Bright |
|    |   | 11 |          | <b>Head 1 Cold White of Ring 4</b>                     |
|    |   |    | 0..255   | 0-100% Cold White of Ring 4 Dimmer from Dark to Bright |
|    |   | 12 |          | <b>Head 1 Warm White of Ring 5</b>                     |
|    |   |    | 0..255   | 0-100% Warm White of Ring 5 Dimmer from Dark to Bright |
|    |   | 13 |          | <b>Head 1 Cold White of Ring 6</b>                     |
|    |   |    | 0..255   | 0-100% Cold White of Ring 6 Dimmer from Dark to Bright |
|    |   | 14 |          | <b>Head 1 Warm White of Ring 7</b>                     |
|    |   |    | 0..255   | 0-100% Warm White of Ring 7 Dimmer from Dark to Bright |
|    |   | 15 |          | <b>Head 1 Cold White of Ring 8</b>                     |
|    |   |    | 0..255   | 0-100% Cold White of Ring 8 Dimmer from Dark to Bright |
|    |   | 16 |          | <b>Head 1 Warm White of Ring 9</b>                     |
|    |   |    | 0..255   | 0-100% Warm White of Ring 9 Dimmer from Dark to Bright |
| 8  | 1 | 17 |          | <b>Head 2 Dimmer</b>                                   |
|    |   |    | 0..255   | Dimmer 0%...100%                                       |
|    |   |    |          | <b>Head 2 Shutter</b>                                  |
|    |   |    | 0..31    | Shutter Closed   |
|    |   |    | 32..63   | Shutter Open   |
|    |   |    | 64..95   | Strobe Effect Slow to Fast                             |
| 9  | 2 | 18 | 96..127  | Shutter Open   |
|    |   |    | 128..159 | Pulse-effect in Sequences Slow to Fast                 |
|    |   |    | 160..191 | Shutter Open   |
|    |   |    | 192..223 | Random Strobe Effect Slow to Fast                      |
|    |   |    | 224..255 | Shutter Open   |
| 10 | 3 | 19 |          | <b>Head 2 Warm White</b>                               |

|          |               |    |          |  |
|----------|---------------|----|----------|--|
| 10       | 3             | 19 | 0..255   | 0-100% Warm White Dimmer from Dark to Bright           |
| 11       | 4             | 20 |          | <b>Head 2 Cold White</b>                               |
|          |               |    | 0..255   | 0-100% Cold White Dimmer from Dark to Bright           |
| 12       | 5             | 21 |          | <b>Head 2 Color Temp</b>                               |
|          |               |    | 0..15    | No Function  |
|          |               |    | 16..45   | Below 3200K  |
|          |               |    | 46..75   | 3200K - 3500K  |
|          |               |    | 76..105  | 3500K - 5000K  |
|          |               |    | 106..135 | 5000K - 5500K  |
|          |               |    | 136..165 | 5500K - 6000K  |
|          |               |    | 166..195 | 6000K - 6500K  |
|          |               |    | 196..225 | 6500K - 7000K  |
|          |               |    | 226..255 | 7000K - 8000K  |
| 13       | 6             | 22 |          | <b>Head 2 Macro RUN</b>                                |
|          |               |    | 0..15    | No function  |
|          |               |    | 16..27   | Macro Run 1  |
|          |               |    | 28..39   | Macro Run 2  |
|          |               |    | 40..51   | Macro Run 3  |
|          |               |    | 52..63   | Macro Run 4  |
|          |               |    | 64..75   | Macro Run 5  |
|          |               |    | 76..87   | Macro Run 6  |
|          |               |    | 88..99   | Macro Run 7  |
|          |               |    | 100..111 | Macro Run 8  |
|          |               |    | 112..123 | Macro Run 9  |
|          |               |    | 124..135 | Macro Run 10   |
|          |               |    | 136..147 | Macro Run 11   |
|          |               |    | 148..159 | Macro Run 12   |
|          |               |    | 160..171 | Macro Run 13   |
|          |               |    | 172..183 | Macro Run 14   |
|          |               |    | 184..195 | Macro Run 15   |
|          |               |    | 196..207 | Macro Sound 1  |
| 208..219 | Macro Sound 2 |    |          |  |
| 220..231 | Macro Sound 3 |    |          |  |
| 232..243 | Macro Sound 4 |    |          |  |
| 244..255 | Macro Sound 5 |    |          |  |
| 14       | 7             | 23 |          | <b>Head 2 Macro Speed</b>                              |
|          |               |    | 0..255   | Macro Speed from Slow To Fast                          |
|          |               | 24 |          | <b>Head 2 Warm White of Ring 1</b>                     |
|          |               |    | 0..255   | 0-100% Warm White of Ring 1 Dimmer from Dark to Bright |
|          |               | 25 |          | <b>Head 2 Cold White of Ring 2</b>                     |
|          |               |    | 0..255   | 0-100% Cold White of Ring 2 Dimmer from Dark to Bright |
|          |               | 26 |          | <b>Head 2 Warm White of Ring 3</b>                     |

|  |    |        |  |
|--|----|--------|--|
|  | 26 | 0..255 | 0-100% Warm White of Ring 3 Dimmer from Dark to Bright |
|  | 27 |        | <b>Head 2 Cold White of Ring 4</b>                     |
|  |    | 0..255 | 0-100% Cold White of Ring 4 Dimmer from Dark to Bright |
|  | 28 |        | <b>Head 2 Warm White of Ring 5</b>                     |
|  |    | 0..255 | 0-100% Warm White of Ring 5 Dimmer from Dark to Bright |
|  | 29 |        | <b>Head 2 Cold White of Ring 6</b>                     |
|  |    | 0..255 | 0-100% Cold White of Ring 6 Dimmer from Dark to Bright |
|  | 30 |        | <b>Head 2 Warm White of Ring 7</b>                     |
|  |    | 0..255 | 0-100% Warm White of Ring 7 Dimmer from Dark to Bright |
|  | 31 |        | <b>Head 2 Cold White of Ring 8</b>                     |
|  |    | 0..255 | 0-100% Cold White of Ring 8 Dimmer from Dark to Bright |
|  | 32 |        | <b>Head 2 Warm White of Ring 9</b>                     |
|  |    | 0..255 | 0-100% Warm White of Ring 9 Dimmer from Dark to Bright |