

Channel Mode: 2CH

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Spark Effect	0	OFF
		1-255	Spark Effect ON 1-100%
2	Warming Up /Clean Function	0-20	Warming up function OFF, and the channel (1) is disabled
		50-100	Warming up function ON, and the channel (1) is Available
		150-200	Cleaning Function (15 Seconds), Channel (1) Disabled

STOP READ BEFORE USE
****Unit Must Be Cleaned After Every Use Or Warranty Will Be Voided****

How To Clean Unit (Click On QR Code) or Follow Instructions Below:

1. Completely turn the off & Unplug All Cables From Unit.
2. Open Cold Spark Granule Powder Cap.
3. Turn Unit 180 Degrees & Dump Out Extra Leftover Granule Powder In Airtight Container.
4. Reconnect Power Cable, Wireless Receiver Cable & Power Unit On.
5. On Remote: Press Power Button, Then Press Clean Bottom (Sparks Will Shoot Out Of Unit).
6. Once Sparks Stop Shooting Out, Unit Is Cleaned & Ready For Storage & Later Use.



****NOTE: Leaving Non-Used Granule Powder In Unit After Use. Will Clog Tube & Bearings VOIDING WARRANTY!!****