

Channel Mode: 10CH

Ch	Function	Value	Description
1CH	Master Dimmer	0	NO
		001-255	Dark to Bright
2CH	R	0	NO
		001-255	Dark to Bright
3CH	G	0	NO
		001-255	Dark to Bright
4CH	B	0	NO
		001-255	Dark to Bright
5CH	W	0	NO
		001-255	Dark to Bright
6CH	C	0	NO
		001-255	Dark to Bright
7CH	Y	0	NO
		001-255	Dark to Bright
8CH	Strobe	0	NO
		001-255	Slow to Fast
9CH	Built-in Program	0	NO
		001-255	16 color selection
10CH	Built-in Speed	0 ²	NO
		001-255	0 invalid 1-127 Jump changes, the higher the value, the faster the speed 128-255 Gradual changes, the higher the value, the faster the speed